

**Directions for use Gold Series "LUX"© Box add-on UV sterilizer with inductive charging function wireless!
A must for each studio to comply with the hygiene regulations of the individual countries of the Federal Republic of Germany.**



Premium cardboard for storage of the box



Read the instructions for use in full and keep it!

These pages are sole property "Die-Profi-Permanent-Liner", copies or reproductions are not permitted without permission.
In the event of misuse, a complaint with an application for damages will be made immediately!

Security

This device should only be used by qualified personnel.
only according to the instructions in the instructions for use.

Use the device

It does not contain any parts to wait. The device is certainly equipped with locking to eliminate exposure to UV radiation.

Never override the locking so that the warranty expires and may endanger you and may lead to skin or eye damage!

If the device is damaged or there is signs of damage, including soot formation on the plastic housing or a failure of the lock, stop use immediately and contact your supplier.

This device should only correspond to power supply devices, such as a laptop or mains adapter with (SELV). The power of the USB output of the power supply device should be 9 Voltdc 2 Amper or 5 Voltdc 2.1 Ampere.

Use only one power adapter or other power supply device with CE marking.

Disconnect the device from the power port when you are not using or waiting for the device.

Do not expose the device to water, other liquids, extreme heat or shocks such as a fall.

The device is only suitable for indoor use not outdoors. Clean the surface of the device only with a damp cloth. Do not use aggressive detergents or chemicals for cleaning, as they could damage the device.



1. This symbol on the device means that used electrical and electronic products must not be mixed with normal household waste. For proper handling, bringing recycling the device to a designated pick-up point/recycling yard.
2. Contact your local authority for details regarding the pick-up point/recycling yard and to obtain any additional local conditions.

Hints

1. Areas that are not exposed to UV rays are not sterile.

2. The sterile effect on the areas of a device may vary depending on the amount of UV radiation, the distance from the light source and other factors.

3. Referring to the sterile effect, the surface on an object, the underside of the device smaller than other areas.

4. Is generally a USB Type - C cable to use. In the case of non-certified USB cables, the performance of the operation and the warranty is not required.

5. There are magnetic strips in the lid of the box. Please make sure that you do not when closing the upper lid.

Product

Product name: UV sterilizer with inductive charging function wireless lysa for the Gold series "LUX"©

Model No. : GP-T0U020DPPL Rated power: 9V-2 A, 5 V - 2.1 A

Power: Inductive charging 10 W Disinfection time: 10 minutes

Disinfection efficient: Up to 99% UV wavelength: 253.7 Nm

Working Temperature: 10 Degrees Celsius x 45 Degrees Celsius

Outer size of box: 228 X 133 -X 49.5 mm

Box interior size: 196 X 96 -X 33 mm Product weight of the box: 369 grams

Scope of delivery:

1 Premium cardboard box for storing the box

1 USB Type - C Cable

1 box UV sterilizer with inductive charging function wireless!

1 Instruction manual for use

1 Hygiene plan according to the countries hygiene regulations of the Federal Republic of Germany training with completion certificate hygiene regulations and plan Optional can be booked in the online shop www.die-profi-permanent-liner.de.

These pages are sole property "Die-Profi-Permanent-Liner", copies or reproductions are not permitted without permission.
In the event of misuse, a complaint with an application for damages will be made immediately!

Product Front



Status Lamp

Switch slightly press the Disinfection process underway 10 minutes and switches then automatically off!

Back



Data

Devices number.

Connection USB
Type C Cable



Ultraviolet lamps

Connection USB Type C Cable

Devices of the Gold Series "LUX"®

These pages are sole property "Die-Profi-Permanent-Liner", copies or reproductions are not permitted without permission. In the event of misuse, a complaint with an application for damages will be made immediately!

Directions

1. Connect your USB Type C cables to the box and a compatible charging adapter.
2. Open the top cover on the box.
3. Place the devices to be disinfected, items, jewelry, mobile phones etc. in the box.
4. Pressing the start switch. The disinfection process starts with a beep and the status LED flashes.
5. The disinfection process is automatically terminated after 10 minutes and the box is switched off.

! If the cover is opened during the disinfection process, the disinfection process stops automatic.

Product

1. The device has been tested by third-party laboratories, resulting in up to 99% bacteria ☆☆☆ within 10 minutes be killed..
2. ☆ Areas of objects that are not exposed to UV light are not disinfected. the Degree of disinfection may vary depending on the area of the item, depending on the various factors such as UV exposure time, length of UV light and surface of the object and similar.
3. ☆ ☆ Including Escherichia coli, staphylococcus, Candida albicans.
4. Modern design with the dual UV lamps allows the disinfection of the desired item inside the box without any problems.
5. ☆ For effective disinfection, it is recommended to disinfect a page and then object and disinfect the other side.
6. ☆ Charging speed may vary depending on usage, loading conditions, and other factors.

Warranty

Factory warranty: The statutory warranty according to Section 437 of the German Civil Code (BGB) is 24 months as a utility, it implies that the equipment and products delivered by us are free of errors in the workmanship and in the material, and begins with the handover of the goods (see accounting). It refers to all equipment and products supplied by us, excluding consumables. During the warranty period, you can | the device that is defective in the shop if the device fails. [Defektes Gerät | Profi Permanent Liner \(die-profi-permanent-liner.de\)](#) and confirmation of this submission and receive in case of warranty/guarantee in a timely exchange for a new product/device. Exception here, the device is damaged by improper use! The replacement is not free of charge here. You will then be offered a price offer for exchange, which will be up to 120,- € net. goes. Prerequisite for the warranty is, the device was purchased from us, see device number. Batteries and lithium-ion accumulators are excluded from the warranty, as well as damage caused by improper use/non-compliance with the safety instructions/unauthorized interference. Please make sure to pack the device appropriately. [Defektes Gerät | Profi Permanent Liner \(die-profi-permanent-liner.de\)](#). The manufacturer assumes responsibility for the safety, reliability and performance of the product only in the event that the repair, replacement or modification of the device is carried out by authorized persons. Furthermore, he assumes responsibility if the device is used correctly according to the instructions for use and the power specifications (current) comply with the legal requirements. Subject to changes in technical data, characteristics, set and printing errors. We provide an additional warranty on the "LUX" series ® and additional equipment supplied by us, i.e. Your warranty will last a total of 3 years!

As a customer and buyer of the device, the replacement also takes place after the warranty period, or in case of wear and tear against a new device for a fee of 120, - € net plus 19% VAT.